• Input Voltage: 12VDC

• Max Capacity: 660lbs (3000N)

• Cycle: 10%

• Operation Temperature: -20°C +65°C


• Noise Level: ≤50dB

• Speed: 5mm/s

• Standard Stroke: 6inch

• Color: Silver

• Waterproof Rating: IP65



### **Receiver and Remote Control**

• Input: DC 12V,

• Output: DC 12V

• Mode: Latched, Locked, Momentary

• Frequency: 433.92MHz

Distance: 20MCurrent: < 8A</li>

- 1 Pair remote control and receiver:
- Press any key on the remote control.
- Connect the power wire of receiver and turn it on.
- Press the red button on the receiver
- Press and hold any key on the remote control for 3 seconds, it is paired with receiver
- 2 Unpair remote control and receiver:
- Press and hold the red button on receiver for 10 seconds to unpair remote control
- 3 To ensure the remote control working distance, please keep the receiver away from interference source.
- 4 Please connect DC 12V power with the receiver.
- 5 The rated cycle is 10%, which means the linear actuator needs a break for 18 minutes for 2 working minutes.
- 6 These are DC linear actuators. When the power wires are reversed, the moving direction is reversed as well.
- **7** Please do not overload the linear actuators more than its maximum capacity.





• Input Voltage: 12VDC

• Max Capacity: 660lbs (3000N)

• Cycle: 10%

• Operation Temperature: -20°C +65°C


• Noise Level: ≤50dB

• Speed: 5mm/s

• Standard Stroke: 8inch

• Color: Silver

• Waterproof Rating: IP65



### **Receiver and Remote Control**

• Input: DC 12V,

• Output: DC 12V

• Mode: Latched, Locked, Momentary

• Frequency: 433.92MHz

Distance: 20MCurrent: < 8A</li>

- 1 Pair remote control and receiver:
- Press any key on the remote control.
- Connect the power wire of receiver and turn it on.
- Press the red button on the receiver
- Press and hold any key on the remote control for 3 seconds, it is paired with receiver
- 2 Unpair remote control and receiver:
- Press and hold the red button on receiver for 10 seconds to unpair remote control
- 3 To ensure the remote control working distance, please keep the receiver away from interference source.
- **4** Please connect DC 12V power with the receiver.
- **5** The rated cycle is 10%, which means the linear actuator needs a break for 18 minutes for 2 working minutes.
- 6 These are DC linear actuators. When the power wires are reversed, the moving direction is reversed as well.
- **7** Please do not overload the linear actuators more than its maximum capacity.





• Input Voltage: 12VDC

• Max Capacity: 660lbs (3000N)

• Cycle: 10%

• Operation Temperature: -20°C +65°C


• Noise Level: ≤50dB

• Speed: 5mm/s

• Standard Stroke: 10inch

• Color: Silver

• Waterproof Rating: IP65



### **Receiver and Remote Control**

• Input: DC 12V,

• Output: DC 12V

• Mode: Latched, Locked, Momentary

• Frequency: 433.92MHz

Distance: 20MCurrent: < 8A</li>

- 1 Pair remote control and receiver:
- Press any key on the remote control.
- Connect the power wire of receiver and turn it on.
- Press the red button on the receiver
- Press and hold any key on the remote control for 3 seconds, it is paired with receiver
- 2 Unpair remote control and receiver:
- Press and hold the red button on receiver for 10 seconds to unpair remote control
- 3 To ensure the remote control working distance, please keep the receiver away from interference source.
- 4 Please connect DC 12V power with the receiver.
- 5 The rated cycle is 10%, which means the linear actuator needs a break for 18 minutes for 2 working minutes.
- 6 These are DC linear actuators. When the power wires are reversed, the moving direction is reversed as well.
- **7** Please do not overload the linear actuators more than its maximum capacity.





• Input Voltage: 12VDC

• Max Capacity: 660lbs (3000N)

• Cycle: 10%

• Operation Temperature: -20°C +65°C


• Noise Level: ≤50dB

• Speed: 5mm/s

• Standard Stroke: 12inch

• Color: Silver

• Waterproof Rating: IP65



### **Receiver and Remote Control**

• Input: DC 12V,

• Output: DC 12V

• Mode: Latched, Locked, Momentary

• Frequency: 433.92MHz

Distance: 20MCurrent: < 8A</li>

- 1 Pair remote control and receiver:
- Press any key on the remote control.
- Connect the power wire of receiver and turn it on.
- Press the red button on the receiver
- Press and hold any key on the remote control for 3 seconds, it is paired with receiver
- 2 Unpair remote control and receiver:
- Press and hold the red button on receiver for 10 seconds to unpair remote control
- 3 To ensure the remote control working distance, please keep the receiver away from interference source.
- 4 Please connect DC 12V power with the receiver.
- 5 The rated cycle is 10%, which means the linear actuator needs a break for 18 minutes for 2 working minutes.
- 6 These are DC linear actuators. When the power wires are reversed, the moving direction is reversed as well.
- **7** Please do not overload the linear actuators more than its maximum capacity.





• Input Voltage: 12VDC

• Max Capacity: 660lbs (3000N)

• Cycle: 10%

• Operation Temperature: -20°C +65°C


• Noise Level: ≤50dB

• Speed: 5mm/s

• Standard Stroke: 18inch

• Color: Silver

• Waterproof Rating: IP65



### **Receiver and Remote Control**

• Input: DC 12V,

• Output: DC 12V

• Mode: Latched, Locked, Momentary

• Frequency: 433.92MHz

Distance: 20MCurrent: < 8A</li>

- 1 Pair remote control and receiver:
- Press any key on the remote control.
- Connect the power wire of receiver and turn it on.
- Press the red button on the receiver
- Press and hold any key on the remote control for 3 seconds, it is paired with receiver
- 2 Unpair remote control and receiver:
- Press and hold the red button on receiver for 10 seconds to unpair remote control
- 3 To ensure the remote control working distance, please keep the receiver away from interference source.
- 4 Please connect DC 12V power with the receiver.
- 5 The rated cycle is 10%, which means the linear actuator needs a break for 18 minutes for 2 working minutes.
- 6 These are DC linear actuators. When the power wires are reversed, the moving direction is reversed as well.
- **7** Please do not overload the linear actuators more than its maximum capacity.



